


# Taster für Zeiss-Anwendungen

Für höchste Präzision verwenden Sie nur Original-Taster von Renishaw. Geben Sie sich nicht mit weniger zufrieden!

## M5 Taster

### Taster mit Rubinkugel (Hartmetall)

<b>A-5555-0018</b> 602030-9010-000 DK 3,0 mm L 25 mm	<b>A-5555-0019</b> 600342-8020-000 DK 3,0 mm L 33,5 mm	<b>A-5555-0020</b> 602030-9011-000 DK 3,0 mm L 50 mm	<b>A-5555-0021</b> 600342-8021-000 DK 3,0 mm L 58 mm	<b>A-5555-0022</b> 600342-8025-000 DK 4,0 mm L 33,5 mm	<b>A-5555-0052</b> 602030-8060-000 DK 8 mm L 32 mm	<b>A-5555-0053</b> 602030-8061-000 DK 1,0 mm L 32 mm	<b>A-5555-0054</b> 602030-8062-000 DK 1,35 mm L 32 mm	<b>A-5555-0055</b> 602030-8063-000 DK 1,35 mm L 44 mm	<b>A-5555-0056</b> 602030-8064-000 DK 1,5 mm L 32 mm	<b>A-5555-0057</b> 602030-8065-000 DK 1,5 mm L 44 mm	<b>A-5555-0058</b> 602030-8066-000 DK 2,0 mm L 32 mm	<b>A-5555-0059</b> 602030-8067-000 DK 2,0 mm L 44 mm	<b>A-5555-0060</b> 602030-8068-000 DK 2,0 mm L 58 mm	<b>A-5555-0061</b> 602030-8069-000 DK 2,5 mm L 32 mm	<b>A-5555-0062</b> 602030-8070-000 DK 2,5 mm L 44 mm	<b>A-5555-0063</b> 602030-8071-000 DK 2,5 mm L 58 mm
---	---	---	---	---	---	---	--	--	---	---	---	---	---	---	---	---



### Taster für Sternstaster (Hartmetall)

<b>A-5555-0078</b> 600342-8200-000 DK 1,35 mm L 32,9 mm	<b>A-5555-0079</b> 600342-8201-000 DK 1,5 mm L 33,0 mm	<b>A-5555-0080</b> 600342-8202-000 DK 2,0 mm L 33,5 mm	<b>A-5555-0084</b> 600342-8250-000 DK 3 mm L 21,8 mm	<b>A-5555-0085</b> 600342-8251-000 DK 0,5 mm L 22 mm	<b>A-5555-0086</b> 600342-8252-000 DK 0,6 mm L 22,1 mm	<b>A-5555-0087</b> 600342-8253-000 DK 0,8 mm L 22,3 mm	<b>A-5555-0088</b> 600342-8254-000 DK 1,0 mm L 22,5 mm
--	---	---	---	---	---	---	---

### Drehadapter (Hartmetall)

<b>A-5555-0099</b> 602030-9095-000 D 18 mm L 30 mm
---

### Halter für Taster (1 - 1,5 mm)

<b>A-5555-0104</b> 600341-8160-000 DK 11 mm L 5 mm
---

### Halter für bis zu 5 Taster (Hartmetall)

<b>A-5555-0105</b> 600341-8367-000 D 11 mm Schaltdurchmesser 1,0 mm L 10 mm	<b>A-5555-0106</b> 600341-8368-000 D 11 mm Schaltdurchmesser 1,5 mm L 10 mm
---	---



### Taster ohne Gewinde - abgestuft (Hartmetall)

<b>A-5555-0107</b> 600341-8454-000 DK 1,0 mm L 16 mm	<b>A-5555-0108</b> 600341-8450-000 DK 0,3 mm L 15,3 mm	<b>A-5555-0109</b> 600341-8451-000 DK 0,5 mm L 15,5 mm	<b>A-5555-0110</b> 600341-8452-000 DK 0,6 mm L 15,6 mm	<b>A-5555-0111</b> 600341-8453-000 DK 0,8 mm L 15,8 mm
---	---	---	---	---

### Taster ohne Gewinde (Hartmetall)

<b>A-5555-0112</b> 600341-8500-000 DK 1,35 mm L 26,4 mm	<b>A-5555-0113</b> 600341-8501-000 DK 1,5 mm L 26,5 mm	<b>A-5555-0114</b> 600341-8502-000 DK 2,0 mm L 27 mm	<b>A-5555-0115</b> 600341-8503-000 DK 2,5 mm L 27,5 mm
--	---	---	---

### Würfel (Titan)

<b>A-5555-0189</b> 600341-8361-000 15 mm x 15 mm	<b>A-5555-0190</b> 600341-8002-000 20 mm x 20 mm
--	--

### Gelenkstücke (Titan)

<b>A-5555-0218</b> 600342-9002-000 L 30 mm D 11 mm	<b>A-5555-0219</b> 600342-9003-000 L 36 mm D 18 mm
---	---

### Adapter (Hartmetall)

<b>A-5555-0228</b> 602030-0215-000 M5 - M2 L 10 mm	<b>A-5555-0227</b> 602030-0315-000 M5 - M3 L 10 mm
---	---

### Verlängerungen (Aluminium)

<b>A-5555-0127</b> 600341-8422-000 D 20 mm L 100 mm	<b>A-5555-0128</b> 600341-8423-000 D 20 mm L 80 mm	<b>A-5555-0130</b> 600341-8425-000 D 20 mm L 40 mm	<b>A-5555-0132</b> 600341-8264-000 D 11 mm L 100 mm	<b>A-5555-0134</b> 600341-8262-000 D 11 mm L 60 mm	<b>A-5555-0135</b> 600341-8261-000 D 11 mm L 40 mm
--	---	---	--	---	---

### Wechselteller (nichtrostender Stahl)

<b>A-5555-0136</b> 600341-0260-000 D 11 mm L 100 mm	<b>A-5555-0140</b> 600341-0252-000 D 11 mm L 20 mm	<b>A-5555-0142</b> 600341-0250-000 D 11 mm L 10 mm
--	---	---

### Verlängerungen (Titan)

<b>A-5555-0145</b> 602030-9046-000 D 11 mm L 20 mm	<b>A-5555-0148</b> 602030-9049-000 D 11 mm L 40 mm	<b>A-5555-0152</b> 602030-9053-000 D 11 mm L 60 mm
---	---	---

### Verlängerungen (temperaturstabile Kohlefaser)

<b>A-5555-0647</b> 626107-1040-100 D 11 mm L 40 mm	<b>A-5555-0648</b> 626107-1050-100 D 11 mm L 50 mm	<b>A-5555-0652</b> 626107-1100-100 D 11 mm L 100 mm	<b>A-5555-0659</b> 626107-2100-100 D 20 mm L 100 mm	<b>A-5555-0663</b> 626107-2200-100 D 20 mm L 200 mm
---	---	--	--	--

### Wechselteller (Aluminium)

<b>A-5555-0255</b> 600667-9601-000 MT/VAST mit ID-Chip	<b>A-5555-1235</b> 620161-8254-000 XXT TL1 Adapterplatte mit ID-Chip	<b>A-5555-1236</b> 620161-8259-000 XXT TL1 Referenz-Wechselteller mit ID-Chip	<b>A-5555-1237</b> 620161-8264-000 XXT TL2 Adapterplatte mit ID-Chip	<b>A-5555-1238</b> 620161-8269-000 XXT TL2 Referenz-Wechselteller mit ID-Chip	<b>A-5555-1241</b> 626103-8431-055 VAST XXL TL1 mit Sternadapter	<b>A-5555-1242</b> 626103-8433-055 VAST XXL TL3 mit Sternadapter
--	--	---	--	---	--	--

## Taster M3 XXT Hartmetall

### Taster mit Rubinkugel

<b>A-5004-3176</b> 626113-0030-013 DK 0,3 mm L 13 mm	<b>A-5004-2186</b> 626113-0050-020 DK 0,5 mm L 20 mm	<b>A-5004-3427</b> 626113-0100-030 DK 1,0 mm L 30 mm	<b>A-5004-1779</b> 626113-0151-040 DK 1,5 mm L 40 mm	<b>A-5555-3855</b> 626113-0201-040 DK 2,0 mm L 40 mm	<b>A-5004-3428</b> 626113-0250-040 DK 2,5 mm L 40 mm
---	---	---	---	---	---

## Referenztaster XXT (roter Punkt)

### Taster mit Rubinkugel (Kohlefaser)

<b>A-5555-2033</b> 626103-0501-030 DK 5,0 mm L 30 mm	<b>A-5555-3858</b> 626103-0501-050 DK 5,0 mm L 50 mm
---	---

